


GENERAL INFORMATION

Overview

SeaKey offers you as a boat owner the ultimate peace of mind, whether you are on board the boat or not.



Any vital data from the boat is sent via the satellite link, and presented on your personal web site, as well as monitored by the 24/7 SeaKey Response Center.

Activate your New SeaKey® V2.0 DM

SeaKey's safety & security features **will only function if your system is activated.**

This unique identifier

Steps to activate your SeaKey subscription:

1. Gather all your relevant contact details, including marina name and phone number where boat will be docked.
2. Have your boat registration with the brand, model, color and Hull Identification Number ready
3. The Satcom ID of your SeaKey unit. This unique identifier is found under the DIAGNOSTIC- ABOUT menu on your Operator Module
4. The SIM card number of your SeaKey unit. This unique identifier is found under the DIAGNOSTIC- ABOUT menu on your Operator Module
5. Call 1-866-4SEAKEY or 1-920-490-1869.

Your SeaKey unit comes with a pre-paid membership trial period. However, you will be requested to provide a credit card at the time you register to avoid any service interruptions.

OPERATING YOUR UNIT

Marine Satcom Unit

SeaKey's MSU is installed behind the helm or below deck. Once activated, it is **always on.**



Operator Module

Use the arrow buttons to move the highlighted menu line to the desired feature and press ENTER.



Function Buttons

Scroll up or choose menu items	↑ ↑
Scroll down or choose menu items	↓ ↓
Adjust contrast	☾
Adjust brightness	☀

Status Bar Symbols

Disconnected GPS antenna	GPS
No satellite signal	SAT
Satellite signal OK	SAT
Alarm triggered, check messages	!
New e-mail	✉

SEAKEY SERVICES

Send SOS Message

An SOS can be triggered by either

- Selecting SOS in the menu and pressing ENTER
- Depressing the SOS switch for 1.5 seconds

Select a description of the emergency from the sub-menu and press ENTER.

The SeaKey Response Center will try to contact you via your registered phone numbers. Whether you can be reached or not, the appropriate actions will be taken until we know that you are safe.

Contact SeaKey

- Scroll to the Contact SeaKey menu item and press ENTER
- Select the most appropriate description from the sub-menu
- SeaKey will call or send you a message

Set Tracking

Mark Waypoint transmits a single position that can be viewed on your personal web site.

Schedule Tracking transmits positions periodically based on your selected interval. Tracking will turn off when the boat is stationary for 2 tracking intervals.

Set Anti-Theft

Activate or deactivate the Geofence alarm that will be triggered if your boat is brought outside a predefined area.

Alarm Status

Lists the status of all relevant sensors and triggers.

Messaging

Receive and send e-mails (restricted to 100 characters).

SEAKEY SERVICES

SEAKEY SERVICES

User Settings

Select your local time zone, set your desired date/time formats, and speed/distance units.

Diagnostics

Monitor the status of sensors, voltage levels and GPS antenna connection. While in the DIAGNOSTIC-SENSORS menu, the alarm sensors can be tested without sending an alarm.

Off Season Power Mode

This function puts the system into a low power mode that will continue to monitor the float switch. The system will fully activate if the SOS button is triggered or main power switch is switched on.

IMPORTANT NOTES

- Do not connect the SeaKey wiring cables to the MSU until after the boat batteries have been installed and connected to the boat's electrical system.
- The boat's position as displayed on your personal web site will only be updated in case of an alarm, when tracking is activated, and periodically when the boat is in port.
- SeaKey is always on, however the Operator Module LCD display will be switched off when you are not using the boat or after 3 hours when the engine is off. Turn on the display again by turning off/on the main power switch.

Document Version: QRG 2005_1.0

SUMMARY OF FEATURES

BOAT SECURITY

- Theft Notification
- Stolen Boat Tracking
- High Water Alarm
- Low Battery Monitoring

BOATER SAFETY

- SOS Messages
- Emergency Alerts
- Coordination of Rescue Services
- On-line Float Plans
- Automatic Arrival Notification

BOATING ENJOYMENT

- Concierge Services
- Web-based Trip Planning
- Two-way Messaging (e-mail)
- Personal Website
- Picture Gallery

For a detailed description of how to operate the SeaKey services, please refer to the SeaKey User Manual, printable from the CD or from your personal web page.

Contact the SeaKey Response Center

Toll-free: 1-866-4SEAKEY or 1-866-473-2539
International: +1 920 490 1869
Email: info@myseakey.com

To log on to your personal web page or for more information:

www.myseakey.com

SeaKey®

BOAT SECURITY. BOATER SAFETY. BOATING ENJOYMENT.

QUICK REFERENCE GUIDE



Always Connected. Always Protected.